

CasaTunes XLi Quick Install Guide

This is a brief guide for installing the CasaTunes XLi into a computer with Windows 7 or WHS 2011, which will be used as a Music Server for up to 6 rooms.

Hardware Installation

1. Ground yourself carefully before handling the XLi card or working inside a computer.
2. Install the XLi card into any PCI-e card slot.
3. Close computer and connect one end of the supplied cables into the Z1 – Z6 connectors on the card. Connect the other end to the XLa or equiv. amplifiers. See the XLa Quick Start for details.
4. Connect your Music Server computer to your local area network (LAN) with an Internet connection.

CasaTunes Software Installation – Important! Use the included disk to install, as it includes important drivers! Requires up to date Windows 7 or WHS 2011

1. Start your Music Server computer, with monitor, keyboard and mouse connected.
2. **Do not let Windows install default hardware drivers!**
3. Insert the CasaTunes XL Installation CD and follow the directions on the screen for “Step 1-Install CasaTunes XL Audio Driver. If you are warned about Microsoft Compatibility, click “Continue anyway”.
4. After rebooting the computer, take the CD out and put it back in so that it starts again and start “Step 2 – Install CasaTunes Application and Components”. Follow the on-screen instructions.

CasaSetup

1. Double click on the CasaTunes Setup icon on Music Server computer desktop. This opens the CasaSetup program for easy setup of CasaTunes. This program can also be started on any remote computer on the network by entering <http://computername/CasaSetup>, where *computername* is the name of the Music Server computer that you installed CasaTunes on.
2. Go through all of the pages of CasaSetup and customize your setup, as necessary. Verify that CasaSetup defaulted to XLi in the controller page. If you need help on any page, click on the help button.