

CasaTunes Setup (Cont)

For any distribution system source input that CasaTunes supplies a music stream, pick CasaTunes Media Player as the Source type and configure the first stream as shown:

▼ CasaTunes Player Settings

Select audio device for source: **Speakers (Intel SST Audio Device (WDM))** ▼

Select speakers for source: **Speaker Pair 1: (Jack Color: Lime Green)** ▼

Configure the second stream (CT-2 only) as shown.

Select audio device for source: **Speakers (USB Audio Device)** ▼

Select speakers for source: **Speaker Pair 1: (Jack Color: Lime Green)** ▼

For other source inputs, select a source type from the pull down menu or choose "Unsupported Source".

Select Controller
Sources
Rooms

My Music
► Music Services
Music Searches

Manage Music Services
Update CasaTunes License
Change Time Zone

Enable all of the music services you are interested in.

Music Services

- ☐ iPod Classic (No WiFi)
- ☐ iTunes Music
- ☐ iNetCustom
- ☒ SHOUTcast
- ☒ Spotify
- ☒ SqueezeBox (Includes Pandora, SiriusXM, Slacker and more)

SqueezeBox Settings

Setup an account on <http://www.MySqueezeBox.com>, then select your music apps, for example Pandora for use with CasaTunes. See [Setup Video](#) and Help for instructions.

Note: You must restart the SqueezeBox server below each time you your music apps.

See which [SqueezeBox Apps](#) are supported by CasaTunes.

▼ SqueezeBox Account Information

User Name: Password:

Some music services require setting up SqueezeBox. Follow the directions in CasaSetup.

Some music services require paid accounts, as noted in CasaSetup.

Now, name all of your sources and rooms and set your Time Zone and Update settings. Check Hide box for any Sources or Rooms not used. Click on Advanced Settings and use the Project Information page to create a backup of the project.

Control

Use our control apps.



OR

Go to <http://CasaServer/CasaTunes> on any PC, or <http://CasaServer.local/CasaTunes> on any Mac connected to the network

Need Help?

Check out the videos at <http://www.YouTube.com/CasaTunes>

Check out our Tech Notes at <http://www.CasaTunes.com/guides>

For live help, email us at support@CasaTunes.com or phone us at 888-855-2272

CasaTunes®

Quick Start Guide: CasaTunes CT-1&2



Use this guide only when using CasaTunes to stream to and control audio distribution systems.

Included Items



Network Cable Qty 1



Serial Cable Qty 1



Power Adapter Qty 1



3.5mm to RCA


Audio Cables Qty 1 (CT-1) or 2 (CT-2) each type



3.5mm to 3.5mm


Connect CasaTunes to distribution system

Note: A detailed CasaTunes Technical Reference and Installation Guide can be found at www.CasaTunes.com/guides, under Owner's Manuals




Use Audio Cables to connect stream outputs to distribution system's RCA or 3.5mm inputs

From external devices (tuners, cable boxes, etc.)



To Speakers

Connect to LAN and Power



CasaTunes Setup

Turn on the system at this time.

Open any browser on the LAN and go to CasaSetup:

PC: <http://CasaServer/CasaSetup>
Mac: <http://CasaServer.local/CasaSetup>

Use CasaSetup to pick the audio distribution system from the "Select Controller Type" pull down. Select IP or Serial and put in the correct parameters.

► Select Controller	Music Services	Update
Sources	Music Searches	License
Rooms		Change

Controller Settings

Select Controller Type: Audio Authority SF-16M ▼

Number of Units: 1 ▼

☐ Are you using a CasaTunes CT-3, CT-3S or CTMS-3 music server or streamer?

Serial Port Settings

Serial Port: COM Port 11 ▼

After clicking on Save, the Sources and Rooms refer to the source inputs and zone outputs of the distribution system you are controlling. (continued on back page).