

CasaTunes

CT-2/3/4/5/6

Multi-Room Music Server



www.CasaTunes.com

Welcome and congratulations on your purchase!

Use this guide to quickly setup and configure your CasaTunes music server by following these steps:

1. Unpack and verify system contents.
2. Connect the music server power, network, control and audio cables.
3. Use the CasaSetup browser application to configure your system.
4. Optionally setup your music server to use WiFi.

Use this guide in conjunction with the QuickStart Guide for your matrix amplifier to setup your system.

What's in the box?



1x
CasaTunes music server



1x
Power adapter



1x
Network cable



1x
USB-to-serial cable



5x
3.5 mm stereo to RCA audio cables



1x
Audio digital optical cable


Music server connections



1. Connect the network cable.
2. If your matrix amplifier is controlled using RS-232 (serial), then plug in and connect the USB-to-serial cable from your music server to the control port on your matrix amplifier.
3. Using the cables provided, connect streams S1-5 and OPT to your matrix amplifier.
4. We recommend connecting all the audio cables, even if your music server is not licensed for all streams. Later, if the customer decides to add more streams, we can update the music server license remotely, without the need to visit the customer's location.

Now follow the QuickStart Guide for your matrix amplifier to connect your music server with your matrix amplifier.

CasaSetup configuration



- 1 Start CasaSetup by opening your browser on your computer and enter the following:

PC: <https://casaserver/casasetup>

MAC: <https://casaserver.local/casasetup>

- 2 Select the **Select Controller** menu item in CasaSetup. Select your matrix amplifier from the list of available Controller Types. Configure the IP or Serial Settings for the matrix amplifier.

- 3 Select the **Sources** menu item in CasaSetup. By default CasaSetup automatically configures a CasaTunes Media Player source for each stream. On the **Sources** page in CasaSetup, you can rename your sources, hide sources, and you can connect and configure any unused matrix sources for other components. For example, a vinyl player, set top box, SONOS, Echo Link, etc.


Select Unsupported Source as the Source Type for these components.

- 4 Select the **Rooms** menu item in CasaSetup to name your rooms and hide any unused rooms.
- 5 Now download the **CasaTunesX** Apps for Android and iOS from the Google Play and Apple Store, respectively.

WiFi Setup

You must be connected to a wired network before you can enable WiFi on your music server. Once you have successfully configured the music server WiFi settings, you can disconnect your CasaTunes music server from your wired network.

- 1 In CasaSetup, select the **WiFi Settings** menu item.



- 2 CasaTunes automatically discovers all the available WiFi Networks. Select the WiFi network you want to use from the **Available Networks** drop down, enter the passcode if prompted, then click on **Connect**.
- 3 To change your WiFi network, or to simply disconnect from your WiFi network, click on **Disconnect**.

Helpful Links



Register your system with CasaTunes. Visit <https://casatunes.com/register> This streamlines the Support process should you need support.



Submit a Support Ticket <https://casatunes.com/ticket>



CasaSetup Manual <https://www.casatunes.com/support/docs/casasetup>



CasaTunesX App Guide <https://www.casatunes.com/casatunesx>



View Other Technical Documentation <https://casatunes.com/guides>

Need to contact Support?

Email: support@casatunes.com | Phone: (+1) 970.237-3140 x2